



### AIR-C23 Rotary Facial & Body Spa Cleaning Massager Pack 4-in-1 Waterproof



#### Features:

- i) The AIR-C23 Rotary Facial & Body Spa Cleaning Massager is a professional cleaning system has rotating head provide a micro mas-sage of the skin that removes dead skin cells. This cleans pores and helps reduce fine lines and wrinkles while leaving your skin ex-tra soft and radiant.
- ii) Powerful device packed in a tiny size works with batteries came with 4 brushes which has body brush, facial brush, facial sponge and pumice.
- iii) Soft and smooth youthful advantage. This is a remarkable skin cleansing system




Contact Info: [sales@air-beautyspa.com](mailto:sales@air-beautyspa.com)



## PERSONAL CARE— CLEANSING

### Introduction

Waterproof facial cleaning massager is a waterproof unit which is ideal for usage at bath room. It operates with 4 exchangeable attachments: body brush, small brush, pumice and face sponge.



### Preparing the unit for usage

#### Inserting the battery

Please make sure that your hands are dry when inserting the battery.

The unit is powered by 4pcs AA batteries. For a longer running time, it is recommended to use alkaline batteries.

1. **Use one hand hold the unit downward** and the other hand hold battery cap with thumb at the “open” mark position.
2. **Pull off the cap.** Refer to following picture.  
*Note: please press a little big during pulling, cap is more easily to be pulled off.*
3. **Insert 4pcs AA batteries.**  
*Note: match battery's +/- symbols with the +/- marks on the main unit.*
4. **Replace battery cap.**

#### Using the unit

Caution: do not use it on broken skin or areas of the skin with rash, severe acne or other skin ailments.

1. Use, for example, a headband to keep your hair away from your face.
2. Apply different applicators to the unit for different usage and press button “①” and begin treatment.

Contact Info: [sales@air-beautyspa.com](mailto:sales@air-beautyspa.com)



## PERSONAL CARE— CLEANSING

### **Small brush:**

Face brush is made of very soft bristles, specially designed for tender face skin. For exfoliation, to achieve the best result, you should first clean your face.

Apply brush with your favorite cleanser. Gently move the brush across your face while making circular movements. Please touch the brush on your face flatly, not with an angle as shown in right picture.

### **Body brush:**

Big brush is supposed to be applied on hand and body. Apply soap or cleaner on hand or body. Then, gently move the brush on your skin surface in circles.

### **Face sponge:**

Cosmetic soft sponge gently massages your skin to activate skin activity to make skin elastic and greatly helps nutrition absorption of your beauty creams used to prevent and erase fine lines & black spots.

After deeply exfoliation and clean, dip sponge with your favorite nutrition.

Gently move the sponge across your face while making circular movements.

### **Pumice:**

Please immerse your foot in warm water for a while. Then, wipe dry.

Apply pumice on foot and move in circles. During rotation, pumice efficiently removes hard cells at elbow or under foot while brushes spin them away.

### **Cleaning and storing**

Clean the unit and all applicators each time after usage.

**Do not use any alcohol, acetone, petrol, abrasive cleaning agents etc, to clean the plastic parts.**

1. Rinse applicators with tap water. Max water temperature is 50 °C or 122 °F
2. For brush, also need to rinse the inside part of the brushes.

*Tips: if the filaments have become deformed, you can restore them to their original shape by rinsing the brush in warm water.*

3. Use damp cloth to wop clean any residues remained on unit body.
4. Let air dry all the parts.
5. Store the unit and parts back to the storage box for next usage.

**Important: if the unit is to be disposed for long time, make sure to take out the batteries.**

### **Maintenance and replacements**

Replace the brushes every 2 to 3 months for good cleaning and exfoliation results. Replace the brush if the deformed filaments can no longer be restored to their original shape. Worn filaments will move impurities around rather than remove them. They could also irritate your skin.

New applicators are available from the shop in which you have purchased the unit.

**Contact Info: [sales@air-beautyspa.com](mailto:sales@air-beautyspa.com)**